

Pipe Boxing - Fitting Instructions



1 Cut to correct length. They come in 1.25m lengths as standard and cut be stacked on top of each other to create height. Remove the tape.



2 If necessary for extra waterproofing run a bead of Marmox MSP360 Sealant & Adhesive along the fold. Then fold to create a 90° angle.



3 If applying to a stud wall of Marmox Multiboard, run a bead of Marmox MSP360 along the edge of the Marmox pipe boxing.



4 If the Marmox pipe boxing is being used against a solid wall then it is recommended to use Marmox Wall Brackets. Use 2 per side of a 1.25m length.



5 This example shows being fitted in the corner against a stud wall and solid wall. Be sure to mark against the wall and drill out the hole positions.



6 Place the Marmox pipe boxing in place and push firmly. Add screw fixings. Run a bead of Marmox MSP360 around the top.



7 Add Marmox MSP360 / Marmox Wall Brackets to the next piece of Marmox pipe boxing and push firmly into place. Add screws.



8 You can seal the edges with Marmox MSP360. The Marmox pipe boxing is now ready to be plastered or tiled.